

# Cooper Interconnect 5015 cross reference list.



Part numbers start with the following numbers

Master P/N	Cooper Interconnect	Amphenol	ITT Cannon	DDK
MS3100A	C3100A	97-3100A	CA3100A	D/MS3100A
MS3100E	C3100E	97-3100E	CA3100E	D/MS3100E
MS3100F	C3100F	97-3100F	CA3100F	D/MS3100F
MS3100R	C3100R	97-3100R	CA3100R	D/MS3100R
MS3101A	C3101A	97-3101A	CA3101A	D/MS3101A
MS3101E	C3101E	97-3101E	CA3101E	D/MS3101E
MS3101F	C3101F	97-3101F	CA3101F	D/MS3101F
MS3101R	C3101R	97-3101R	CA3101R	D/MS3101R
MS3102A	C3102A	97-3102A	CA3102A	D/MS3102A
MS3102E	C3102E	97-3102E	CA3102E	D/MS3102E
MS3102F	C3102F	97-3102F	CA3102F	D/MS3102F
MS3102R	C3102R	97-3102R	CA3102R	D/MS3102R
MS3106A	C3106A	97-3106A	CA3106A	D/MS3106A
MS3106E	C3106E	97-3106E	CA3106E	D/MS3106E
MS3106F	C3106F	97-3106F	CA3106F	D/MS3106F
MS3106R	C3106R	97-3106R	CA3106R	D/MS3106R
MS3108A	C3108A	97-3108A	CA3108A	D/MS3108A
MS3108E	C3108E	97-3108E	CA3108E	D/MS3108E
MS3108F	C3108F	97-3108F	CA3108F	D/MS3108F
MS3108R	C3108R	97-3108R	CA3108R	D/MS3108R

